


Nova430i

Outdoor 4x250mW eNB

Installation Guide



About This Document

This document is a guidance of Nova430i hardware installation for installation personnel, including the preparation of installation tools and supporting materials, the demands for installation environment, installation procedure, cable connection and power on.

Accomplish the installation of the device according to this guide, the installation personnel can avoid potential damage to the device during the installation procedure, which makes sure the subsequent good running of the device.

This document suits for the models of pBS3101s eNodeB (eNB).

Copyright Notice

Baicells Technologies, Inc., copyrights the information in this document. No part of this document may be reproduced in any form or means without the prior written consent of Baicells Technologies, Inc. Refer to the "Contact Us" section below.

Disclaimer

The information in this document is subject to change at any time without notice. For more information, please consult with a Baicells technical engineer or the support team.

Disposal of Electronic and Electrical Waste



Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

Exclamation Mark

According to Article 10 (10) of Directive 2014/53/EU, the packaging shows that this radio equipment will be subject to some restrictions when placed on the market.



AT	BE	CY	CZ	DK	EE	FI
FR	DE	EL	HU	IE	IT	LV
LT	LU	MT	NL	PL	PT	SK
SI	ES	SE	UK	BG	RO	HR

Revision Record

Date	Version	Description
------	---------	-------------

15 July, 2024	01	Initial Released.

Contact Us

	Baicells Technologies Co., Ltd.	Baicells Technologies North America, Inc.
	China	North America
Address	9-10F, 1st Bldg., No.81BeiqingRoad, Haidian District, Beijing, China	555 Republic Dr., #200, Plano, TX 75074, USA
Phone	400-108-0167	+1-888-502-5585
Email	contact@Baicells.com or support@Baicells.com	sales_na@Baicells.com or support_na@Baicells.com
Website	www.Baicells.com	https://na.Baicells.com

Safety Information

For the safety of installation personnel and for the protection of the equipment from damage, please read all safety warnings. If you have any questions concerning the warnings, before installing or powering on the base station contact the Baicells support team.



Warning IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.



Warning Read the installation instructions before you connect the system to its power source.

 **Warning** Installation of the equipment must comply with local and national electrical codes.

 **Warning** This product relies on the existing building or structure for short-circuit (overcurrent) protection. Ensure that the protective device is rated no greater than 20A.

 **Warning** Do not operate this wireless network device near unshielded blasting caps or in an explosive environment unless the device has been modified and qualified for such use.

 **Warning** In order to comply with the United States Federal Communications Commission (FCC) radio frequency (RF) exposure limits, antennas should be located at a minimum of 20 centimeters (7.9 inches) or more from the body of all persons.

Table of Contents

1.	Product Overview	1
1.1	Introduction	1
1.2	Highlights	1
1.3	Appearance	2
1.4	Technical Specification	4
1.4.1	Technology	4
1.4.2	Interface	4
1.4.3	Performance	5
1.4.4	Modulation Levels (Adaptive)	6
1.4.5	Features	7
1.4.6	Link Budget	8
1.4.7	Physical	8
2.	Installation Preparation	10
2.1	Support Materials	10
2.2	Installation Tools	10
2.3	Installation Environment	11
2.3.1	Location & Environment	11
2.4	Personnel Requirements	12
2.5	Lightening & Grounding Protection	12
3.	Installation	13
3.1	Unpacking	13
3.2	Installation Procedure	13
3.3	Install on Pole	13
3.4	Install on Wall	15
3.5	Connect Cable	16

3.5.1	Cable Laying Requirements	16
3.5.2	Connect Ethernet Cable	16
3.5.3	eNB Grounding.....	16
3.5.4	Pole Grounding.....	17
3.6	Maintenance Chamber Waterproofing	19
3.7	Power on to Check LED Status	19
4.	Attentions	20
4.1	FAQ	20
4.2	Common Installation Errors	20
Appendix A	Terminology & Acronym	22
Appendix B	Regulatory Compliance	24
	FCC Compliance	24
	ISED Compliance	24

List of Figures

Figure 1-1 Nova430i Appearance.....	2
Figure 3-1 Installation Process.....	13
Figure 3-2 Pre-assembled Device.....	14
Figure 3-3 Wall Bracket.....	15
Figure 3-4 eNB Grounding.....	17
Figure 3-5 Pole Grounding.....	18

List of Tables

Table 1-1 Nova430i Interface Description.....	3
Table 1-2 Nova430i LED Indicators.....	3
Table 2-1 Support Materials.....	10
Table 2-2 Environmental Requirements.....	12

1. Product Overview

1.1 Introduction

The Baicells Nova430i is an advanced two-carrier outdoor eNodeB (eNB) compliant with 3GPP LTE TDD technology. This 4x250mW eNB operates in Carrier Aggregation (CA) mode or Dual Carrier (DC) mode.

In CA mode, Nova430i supports 2CC (2 component carriers) DL/UL CA. 2CC DL/UL CA doubles DL/UL peak throughput comparing to that of a single carrier. By aggregating 2 separated spectrum resources into a virtual contiguous spectrum resource. In DC mode, each carrier is treated as an independent cell, supporting 128+128 users with each cell supporting 5, 10, 15, or 20MHz bandwidth. Using a Nova430i in DC mode simplifies and streamlines the deployment of split sectors.

In addition, HaloB (an embedded EPC option) is available on the Nova430i as part of the base software. The Baicells patented HaloB solution migrates the necessary core network functions to the eNB.

1.2 Highlights

Following are some of the key Nova430i highlights.


- Standard LTE TDD Band 48
- GUI-based local and remote Web management
- Compact, all-in-one design of internal antenna and GPS
- Excellent Non-Line-of-Sight (NLOS) coverage
- Peak rate: Up to DL 290Mbps and UL 70Mbps with 2x20MHz bandwidth
- 2CC DL/UL CA improves the spectrum efficiency of fragmented spectrum resources.
- Suitable for private and public deployments; any IP based backhaul can be used, including public transmission protected by Internet Protocol Security (IPsec)
- 128 RRC connected users per carrier (128+128 in DC mode); upgradeable to higher capacity in future releases

- Integrated small cell form factor for quick and easy installation
- Configured out of the box to work with Baicells Cloud Core
- HaloB as embedded EPC solution
- Supports Transparent Bridge Mode
- Supports Citizens Broadband Radio Service (CBRS) with proxy/direct Spectrum Access System (SAS)
- Supports Multi Operator Radio Access Network (MORAN)
- Support Inter Cell Interference Coordination (ICIC) with static
- Plug-and-play with Self-Organizing Network (SON) capabilities
- Inter operation with all standard LTE Evolved Packet Core (EPC)
- Supports TR-069 network management interface
- Lower power consumption, which reduces OPEX, can be powered easily by Baicells compact outdoor smart UPS

1.3 Appearance

The Nova430i eNB appearance is shown in Figure 1-1.

Figure 1-1 Nova430i Appearance



The Nova430i interfaces are described in Table 1-1.

Table 1-1 Nova430i Interface Description

Interface Name	Description
ETH	RJ-45 interface (FE/GE) Used for power supply, debug or data backhaul. PoE++, complied with IEEE 802.3bt standard
OPT	Reserved optical interface.

The Nova430i interface indicators are described in Table 1-2.

Table 1-2 Nova430i LED Indicators

Identity	Color	Status	Description
PWR	Green	Steady On	Power on
		OFF	No power supply
CELL1	Green	OFF	CELL1 is in inactivated
		Fast flash: 0.1s on,0.1s off	CELL1 is in deactivated
		Slow flash: 1s on,1s off	CELL1 is in activated
CELL2	Green	OFF	CELL2 is in inactivated
		Fast flash: 0.1s on,0.1s off	CELL2 is in deactivated
		Slow flash: 1s on,1s off	CELL2 is in activated
ALM	Red	Steady On	Hardware alarm
		OFF	No alarm

1.4 Technical Specification

1.4.1 Technology

Item	Description
Standard	LTE TDD RAN (3GPP R15 compliant)
TDD UL/DL Configuration	1, 2, 6 (with Special Subframe Configuration 7)
Frequency Band	B48 (3550 MHz – 3700 MHz)
Channel Bandwidth	SC: 5/10/15/20 MHz CA: 40 MHz as maximum aggravated bandwidth
Multiplexing	MIMO: 2x2 (DL)
Security	Radio: SNOW 3G/AES-128 Backhaul: IPsec (X.509 AES-128, AES-256, SHA-128, SHA-256)

1.4.2 Interface

Item	Description
Ethernet Interface	1 RJ-45 Ethernet interface (1 FE/GE)
Power Supply	PoE++ (IEEE 802.3bt compliant)
Protocols Used	IPv4/IPv6 (Dual Stack), UDP, TCP, ICMP, SNMPv2c, NTP, SSH, IPsec, TR-069, HTTP/HTTPs, 1588v2, DHCP
Network Management	IPv4/IPv6, HTTP/HTTPs, SNMPv2c, TR-069, SSH, Embedded EPC
VLAN/VxLAN	802.IQ/VxLAN
LED Indicators	4 x status LED CELL1/CELL2/ALM/PWR

1.4.3 Performance

Item	Description		
Peak Data Rate (DC)	2x20 MHz	DL (Mbps)	UL (Mbps)
	UL/DL Config 1	2x105	2x28
	UL/DL Config 2	2x145	2x14
	UL/DL Config 6	2x85	2x35
	2x10 MHz	DL (Mbps)	UL (Mbps)
	UL/DL Config 1	2x51	2x14
	UL/DL Config 2	2x70	2x7
	UL/DL Config 6	2x42	2x17
Peak Data Rate (CA)	2x20 MHz	DL (Mbps)	UL (Mbps)
	UL/DL Config 1	210	56
	UL/DL Config 2	290	28
	UL/DL Config 6	170	70
	2x10 MHz	DL (Mbps)	UL (Mbps)
	UL/DL Config 1	102	28
	UL/DL Config 2	140	14
	UL/DL Config 6	84	34
	20MHz + 10MHz	DL (Mbps)	UL (Mbps)
	UL/DL Config 1	156	42
	UL/DL Config 2	215	21
	UL/DL Config 6	127	52
	20MHz + 15MHz	DL (Mbps)	UL (Mbps)
	UL/DL Config 1	182	49

Item	Description		
	UL/DL Config 2	250	24
	UL/DL Config 6	148	61
User Capacity	Up to 128 RRC connected users per cell (4 users per TTI) • SC/CA: 128 RRC connected users • DC: 128+128 RRC connected users		
Maximum Deployment Range	5 kilometers		
Latency	30 milliseconds		
Receive Sensitivity	-100 dBm (per channel)		
Modulation	MCS0 (QPSK) to MCS27 (256QAM) DL: QPSK, 16QAM, 64QAM, 256QAM UL: QPSK, 16QAM, 64QAM		
Transmit Power Range	0 to 24 dBm per channel (combined +30dBm, configurable) (1 dB interval)		
Quality of Service	Nine-level priority indicated by QoS Class Identifiers (QCI)		
ARQ/HARQ	Yes		
Synchronization	GPS (built-in), 1588v2		

NOTE: The test method of receiving sensitivity is proposed by the 3GPP TS 36.104, which is based on 5MHz bandwidth, FRC A1-3 in Annex A.1 (QPSK, R=1/3, 25RB) standard.

1.4.4 Modulation Levels (Adaptive)

MCS	Modulation Scheme	RSRP (dBm)	Coverage Distance (km)
0 - 4	QPSK	$-120 \leq \text{RSRP} < -110$	$4 < D \leq 5$
5 - 9	16QAM	$-110 \leq \text{RSRP} < -100$	$3 < D \leq 4$

MCS	Modulation Scheme	RSRP (dBm)	Coverage Distance (km)
10 - 19	64QAM	$-100 \leq \text{RSRP} < -85$	$2 < D \leq 3$
20 - 27	256QAM	$\text{RSRP} \geq -85$	$D \leq 2$

NOTE: The information provided is for reference only as the environment can impact modulation levels.

Scenario: Base Station height is 30 meters; Customer User Equipment (CPE) height is two meters.

1.4.5 Features

Item	Description
Voice	VoLTE*
NSA	Supported
SON	Self-Organizing Network - Automatic setup - Automatic Neighbor Relation (ANR) - PCI confliction detection
EPC	HaloB (Embedded EPC)
Traffic Offload	Local breakout
Layer 2 Support	Transparent Bridge Mode
Maintenance	- Local/Remote Web maintenance - Online status management - Performance statistics - Fault management - Local/Remote software upgrade - Logging - Connectivity diagnosis - Automatic start and configuration - Alarm reporting - User information tracing - Signaling trace

* Planned for future release

1.4.6 Link Budget

Item	Description
Antenna	Integrated 4T4R antennas - Horizontal Beam width $65\pm 10^\circ$ - Vertical Beam width 17° - Polarization: $\pm 45^\circ$
Electrical Down Tilt	6°
Antenna Gain	13 ± 1 dBi
Maximum EIRP	43 ± 1 dBm
Power Control	UL Open-loop/Closed-loop Power Control, DL Power Allocation (3GPP TS 36.213 compliant)

1.4.7 Physical

Item	Description
Surge Suppression	Yes
Power Interface Lightning Protection	Differential mode: ± 10 KA Common mode: ± 20 KA
MTBF	≥ 150000 hours
MTTR	≤ 1 hour
Ingress Protection Rating	IP65
Operating Temperature	-40°F to 131°F / -40°C to 55°C
Storage Temperature	-49°F to 158°F / -45°C to 70°C
Humidity	5% to 95% RH
Atmospheric Pressure	70 kPa to 106 kPa

Item	Description
Power Consumption	Typical 20W, maximum 25W
Weight	10.7lbs / 4.85kg (without bracket)
Dimensions (HxWxD)	12.6 x 8.9 x 4.1 inches/319 x 227 x 104 millimeters
Installation	Pole or wall mount

2. Installation Preparation

2.1 Support Materials

In addition to industry standard tools, you will need the materials described in Table 2-1 during the installation.

Table 2-1 Support Materials

Item	Figure	Description
Ethernet cable		Outdoor CAT6, shorter than 100 meters (~109 yards) It is suggested that the diameter of the cable is 7 ± 1 mm.
Ground cable		If the length of lead is more than 10 meters, a ground cable with 16mm ² cross section should be used. If the length of lead is less than 10 meters, a ground cable with 10mm ² cross section should be used.
Pole		The diameter of the pole is between 40mm to 100mm of hot-galvanized steel pipe. Channel steel and equal angle steel installation are also supported. The width of the channel steel is 50mm to 100mm; the length of side of the angle steel is 63mm to 80mm.
Distribution box		PoE adaptor, power grounding point, broadband access is all in the distribution box, which must be waterproofed.

2.2 Installation Tools

The following tools are needed during the installation.

				
Level bar	Marking pen	Knife	Vise	Wrench
				
Percussion drill and some drill heads	hammer	Cross screwdriver	Cable vice	Tape measure
				
5mm L-shape allen wrench	T7 screwdriver head	Ladder	compass	fixed pulley
				
multimeter				

2.3 Installation Environment

2.3.1 Location & Environment

In addition to network planning, when determining where to place the eNB you need to consider factors such as climate, hydrology, geology, the possibility of earthquakes, reliable electric power, and transportation access. Avoid locating the eNB in areas where there may be extreme temperatures, harmful gases, unstable voltages, volatile vibrations, loud noises, flames, explosives, or electromagnetic interference (e.g., large radar stations, transformer substations). Avoid areas prone to impounded water, soaking, leakage, or condensation.

Table 2-2 provides typical environmental specifications for this eNB.

Table 2-2 Environmental Requirements

Item	Range	Typical value
Temperature	-40°C to 55°C	25°C
Relative humidity (no condensation)	0% to 100%	5% to 95%
Safety voltage	42V to 58V	48V

2.4 Personnel Requirements

The installation personnel must master the basic safe operation knowledge, through the training, and having the corresponding qualifications.

2.5 Lightning & Grounding Protection

You must protect the eNB against lightning. Following are guidelines concerning grounding.

- The yellow-green ground wire must be at least 10mm² in diameter.
- In principle, always place the grounding as near as possible to the equipment.
- Connect to a reliable outdoor grounding point (earth) using one ground screw.
- The connection of the grounding points and ground bar need to be tight and reliable. Rustproofing the terminals, e.g., with anti-oxidant coating or grease, is required.

3. Installation

3.1 Unpacking


Before opening the box, make sure the package is in good condition, undamaged and not wet. During the unpacking, avoid potential damaging impacts from hits or excessive force.

Once unpacked, check whether the quantity is consistent with the packing list.

3.2 Installation Procedure

Figure 3-1 provides an overview of the installation process.

Figure 3-1 Installation Process




3.3 Install on Pole


Check to ensure the diameter of the pole is in the range of 1.6inch to 2.8inch (40mm to 70mm). The position of the eNB on the pole should be at least 47 inch (120 cm) in height. Follow the steps below to install the eNB on a pole.


The brackets have been pre-assembled in manufacturing before packing. It includes two parts, one is pre-assembled on the back of device. The other is for pole mounting or wall mounting, as shown in Figure 3-2.


Figure 3-2 Pre-assembled Device




Following will introduce how to fix the pre-assembled eNB on a pole.

- 

1 Put the pole bracket against the pole.
NOTE: the arrow must be upward.
- 

2 Assemble two omega clamps back and fasten four nuts on the back of the bracket.
- 

3 Hung the eNB (with bracket) on the pole bracket. Ensure the hook on the eNB bracket is stuck in the slot.
- 

4 Fasten the screw on the top of the bracket using a cross screwdriver.


After installation, adjust the eNB to a proper angle by adjusting the adjustable bracket.

3.4 Install on Wall


NOTE: The wall must bear at least 4 times the weight of the eNB.

Take apart assembly bracket first, only remains the wall bracket, as shown in Figure 3-3.


Figure 3-3 Wall Bracket




Following steps introduce how to fix the pre-assembled eNB on a wall.



- 1 Fit the installation bracket on the wall and mark drilling locations with a marker pen.
NOTE: the arrow must be upward.



- 2 Drill two holes at the marked locations and install expansion bolts.
And then hang the wall bracket on expansion bolts, and fasten with flat washers, spring washers and nuts.



- 3 From top to bottom, clip the eNB into the hook on the bracket and tighten the pin on the top of the bracket.

3.5 Connect Cable

3.5.1 Cable Laying Requirements

General requirements:

- Bending radius of power cable and grounding cable: > tripled of the diameter of the cable.
- Bind the cables according the type of the cable, intertwining and crossing are forbidden.
- An identification label should be attached after the cable is laid.

Grounding laying requirements:

- The grounding cable must connect to the grounding point.
- The grounding cable must be separate with the signal cables, of enough distance to avoid signal interference.

3.5.2 Connect Ethernet Cable

Refer Figure 3-4 to complete the Ethernet cable connection.

1. Connect the Ethernet cable to **ETH** interface in the wiring cavity.
2. Lay the Ethernet cable along the wire groove, and stretch out the wiring cavity from **ETH** hole.
3. The Ethernet cable connect to the PoE interface of the PoE adaptor.
4. The LAN interface of the PoE adaptor connect to a LAN switch or a router for maintenance and backhaul.


NOTE: The PoE adaptor must be placed in the distribution box for waterproof.

3.5.3 eNB Grounding

Prepare the grounding cable according to the actual measurements and requirements of the specific installation site. The eNB has two grounding screws located on the bottom of the unit, as shown in Figure 3-4. Follow the steps below the figure to connect the ground cable.

1. Unscrew one grounding screw, connect one end of the ground cable to the grounding screw, and fasten it again.
2. Once the eNB is installed at the outdoor location, the other end of the ground cable needs to connect to a good grounding point.


Figure 3-4 eNB Grounding



3.5.4 Pole Grounding

The purpose of the pole grounding is to protect the equipment in the station from the damage of lightning overvoltage as far as possible. However, the interfaces between the eNB and the outside world mainly include power system, grounding system, antenna feeder and lightning receiving device, and signal line. Therefore, the damage caused by lightning mainly comes from the voltage difference between the equipment in the eNB and one or more of the four interfaces. The pole grounding is shown in Figure 3-5.

Figure 3-5 Pole Grounding



1. The installation position of the grounding bar shall meet the design requirements. The holding pole and tower body must be connected to the lightning protection network or grounded with a separate lead.
2. The diameter of the grounding wire meets the design requirements. The copper nose must be used for grounding, and the grounding resistance is required to be less than 10 ohms. If the resistance of the public network communication equipment placed in other systems is less than 10 ohms, the grounding network of the system should be overlapped.
3. The grounding wire must be the whole wire material. When laying, it should be bound separately with other cables. All grounding wires should be fixed with wire code or binding tape with a fixed spacing of 0.3m. The appearance should be straight and beautiful.
4. The copper bar must be used for the grounding bar, and the specification of the grounding bar shall meet the design requirements. If there are no specific requirements in the design, 300 × 40 × 4mm and fixed with expansion bolts.
5. The grounding wire must be made of the whole cable material, the intermediate joint is strictly prohibited, and the excess length should be cut. The skin shall be complete, and the insulation resistance of the core wire to the ground (or metal isolation layer) shall meet the technical requirements of the cable.
6. The grounding wire shall be connected to the integrated grounding bar of the

building. If it is impossible to connect to the integrated grounding bar of the building, the appropriate grounding point can be selected according to the integrated grounding situation of the indoor building. The selection of grounding point must be higher than the grounding grid, and the feeder grounding shall be towards the downward direction of the feeder, never upward.

7. The grounding electrode of the self-built grounding grid for the outdoor antenna of the tunnel must meet the design requirements. The buried depth of the grounding electrode and the welding quality of the flat iron meet the specification requirements. In principle, the buried depth of the grounding electrode shall not be less than 0.7m. The non-self-built grounding network shall be connected to the grounding network of the owner.
8. The eNB grounding, power adapter grounding, distribution box grounding and feeder grounding must be connected to the grounding bar independently, and the grounding bar must have a path from the lead to the earth.

3.6 Maintenance Chamber Waterproofing

When all the installation has been completed, it is necessary to close the maintenance chamber of the equipment and play the role of waterproof at the same time.

Put the Ethernet cable on the wire, and seal the wire diameter $7 \pm 1\text{mm}$.

3.7 Power on to Check LED Status


Power on the eNB, then wait a few minutes while the eNB boots up. Per the previous Figure 1-1 and Table 1-2 in “1.3 Appearance”, check that the LED indicators are lighting as expected.



4. Attentions

4.1 FAQ

1. How to choose the position of holding pole in the roof
 - 1) Not near the edge.
 - 2) The position of non-bearing beam cannot be selected.
 - 3) Do not choose the side close to the barrier, you need to choose the most open position.
2. The coverage of eNB signal is not ideal after opening
 - 1) Check if the power is full in the base station configuration.
 - 2) Check whether the equipment has standing wave alarm. If there is any alarm, please handle it in time.
 - 3) Check whether the RF frequency band of the equipment is consistent with that of the antenna.
 - 4) Check whether the dip angle planning of the base station is reasonable.
 - 5) Whether there is blocking in antenna coverage direct vision.

4.2 Common Installation Errors



The holding pole lightning rod is not led to the ground bar	Disordered wiring of distribution box
	
Without the lightning rod	Power line and signal cable are crossed
	
Multiply the grounding point	

Appendix A Terminology & Acronym

Acronym	Full Name
ANR	Automatic Neighbor Relations
ARQ	Automatic Repeat Request
CA	Carrier Aggregation
CC	Component Carriers
CSFB	Circuit Switched Fallback
DC	Dual Carrier
EPC	Evolved Packet Core network
GPS	Global Positioning System
HARQ	Hybrid Automatic Repeat Request
IPsec	Internet Protocol Security
MIMO	Multi Input Multi Output
MME	Mobility Management Entity
MOCN	Multi-Operator Core Network
NLOS	Non-Line-of-Sight
OPEX	Operating Expense
PAP	Password Authentication Protocol
PCI	Physical Cell Identifier

Acronym	Full Name
PLMN	Public Land Mobile Network
QAM	Quadrature Amplitude Modulation
QCI	QoS Class Identifiers
QoS	Quality of Service
QPSK	Quadrature Phase Shift Keying
RSRP	Reference Signal Receiving Power
SSH	Secure Shell
SON	Self-Organized Network
TAC	Tracking Area Code

Appendix B Regulatory Compliance

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 40cm between the radiator & your body.

ISED Compliance

This device complies with Innovation, Science, and Economic Development

Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Science et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 40cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter, End-Users must be provided with transmitter operation conditions for satisfying RF exposure compliance.

Les antennes utilisées pour cet émetteur doivent être installées de façon à offrir une distance de séparation d'au moins 40cm entre toutes les personnes et ne doivent pas être colocalisées ou fonctionner conjointement avec d'autres antennes ou transmetteurs. pour satisfaire la conformité à l'exposition RF.